Determination of Ozone Concentration in the Presence of Chlorine Using CHEMetrics® Ozone Test Kits (DPD Chemistry) Cat. Nos. K-7423 and K-7404

Version 2 / Apr 2023

Determining Ozone in the Presence of Chlorine

Chlorine causes a false positive interference (develops color) with colorimetric ozone tests that employ the DPD chemistry. CHEMetrics has developed a procedure to correct for chlorine interference with our Ozone Vacu-vials® Test Kit, Cat. No. K-7423 and Ozone CHEMets® Test Kit, Cat. No. K-7404.

CHEMetrics has confirmed experimentally that the addition of a controlled amount of a glycine solution (Cat. No. A-2700) to the sample will destroy the ozone and allow for the accurate determination of ozone concentration by difference. This protocol can be used in samples containing up to 2 ppm chlorine.

Test Procedure Using K-7423 Vacu-vials® Kit

- 1. Add 5 drops of A-2700* Neutralizer Solution to the empty sample cup.
- 2. Fill the sample cup to the 25 mL mark with the sample to be tested. Stir to mix the contents of the cup. Wait 2 minutes.
- 3. Add 5 drops of A-7400 Activator Solution to the sample cup. Stir to mix the contents of the cup.
- 4. Immediately place the Vacu-vial ampoule, tip first, into the sample cup. Snap the tip. Invert the ampoule several times, allowing the bubble to travel from end to end. Dry the ampoule.
- Wait 1 minute after snapping the ampoule tip, then use this ampoule to set zero on your photometer.

- 6. Using a second ampoule, analyze the sample according to the K-7423 Vacu-vials test kit instructions.
- 7. Obtain a test result with the photometer that was zeroed with the ampoule generated in steps 1-5.

Test Procedure Using K-7404 CHEMets® Kit

- A. Analyze the sample according to the K-7404 CHEMets kit instructions. Record the test result.
- B. Add 5 drops of A-2700 Neutralizer Solution to the empty sample cup.
- C. Fill the sample cup to the 25 mL mark with the sample to be tested. Stir to mix the contents of the cup. Wait 2 minutes.
- D. Add 5 drops of A-7400 Activator Solution to the sample cup. Stir to mix the contents of the cup.
- E. Immediately place the CHEMet ampoule, tip first, into the sample cup. Snap the tip. Invert the ampoule several times, allowing the bubble to travel from end to end.
- F. Obtain a test result 1 minute after snapping the tip.
- G. Subtract the test result obtained in Step F from the test result obtained in Step A to determine the ozone concentration of the sample.

*A-2700 must be purchased separately.